



REPLACE TOP PIPE ELBOW OF SV-I-T BRACKET WITH TEE TO ACCOMMODATE MOUNTING OF EMERGENCY VEHICLE PREEMPTION DETECTOR.

VERIFY LOCATION OF EXISTING SS BEFORE TRENCHING.

INSTALL SIDEWALK AND CASE A CURB RAMP PER JULY 2004 CALTRANS STANDARD PLAN A88A. SEE CIVIL PLANS FOR DETAILS.

**Traffic Signal Cabinet  
5494 Paseo Padre Parkway**

REMOVE EXISTING TYPE P CONTROLLER CABINET FOUNDATION. INSTALL NEW TYPE P CONTROLLER CABINET FOUNDATION PER JULY 2002 CALTRANS STANDARD PLAN ES-3C. TOP OF FOUNDATION SHALL BE 6" ABOVE SURROUNDING GRADE. INSTALL PCC PAD BETWEEN BACK OF WALK AND CABINET FOUNDATION. INSTALL TYPE P CONTROLLER CABINET AND TYPE 90 CONTROLLER. [24]

INSTALL TYPE II-A SERVICE EQUIPMENT ENCLOSURE ON SIDE OF CONTROLLER CABINET. SEE WIRING DIAGRAM ON SHEET TS2.

PROTECT EXISTING WATER VALVE BOX.

REMOVE EXISTING CURB RAMP. INSTALL CASE D CURB RAMP PER JULY 2004 CALTRANS STANDARD PLAN A88A. SEE CIVIL PLANS FOR DETAILS.

STREET LIGHT POLE. REMOVE FOUNDATION. INSTALL NEW FOUNDATION AT SAME LOCATION.

FOR ADDRESSING PURPOSES ONLY  
SP42-0036 5/19/2008 RC